SPORT SAILER
Skeetspot Projects
P.O. BOX 96, Mill Creek, CA 95551

SPORT SAILER

The 12' SPORT SAILER is a fast handling, agile little sailboat that will produce a lot of fun for the money and time invested in building her. With raising daggerboard and rudder, she's easy to beach-launch, and tie down hook/lifting handles make it a snap to car top the 100 pound hull. The plastic sail has been used by us in many wind-powered projects over the last ten years and will provide a cheap, easy-to-make, durable sail that can weather the stiffest gusts with the best of them.

We used water-mixed, waterproof marine glue found in lumber yards. It seems to hold as well as the two-part resorcinol glue, is much cheaper, and there seems to be less waste.

Clear fir was used for the framing and control surfaces, although other medium hardwoods such as spruce or mahogany can be substituted if needed. Most pine is too soft to hold a screw well, which can be important when working with flexed panels.

Actual lumber sizes will vary slightly, but generally when we call for a certain "stock" such as 1" x 6", 2" x 4", etc. the actual sizes will be slightly less. A typical 2" x 4" is actually about 1½" x 3½", and a 1" x 4" is often ¾" x 1⅛" and so on.

Generally, the building steps are split up into four basic steps: Lofting, Cutting, Assembling and Finishing.

In Lofting the more intricate panel layouts, you may find it easier to follow the sequence shown, marking each line as it's numbered to simplify the geometry a little. When making a full size drawing on parallel "station lines" (as in Fig. #2), it's often a good idea to write the dimension next to the mark to keep the sequence straight. And it's always a good practice to run a quick re-check of the dimensions and your marking of them, just before you cut. It's awfully hard to make it grow back together if it's cut too short.

LOFTING:

To loft the curves, we simply draw the parallel station lines one foot apart, mark the dimensions on each line off/set from the centerline, then drive nails down into each off/set mark. Then a batten (you can use a stringer) is pushed up against the inside of the curve marked by the nails. Starting at one end, push the batten up against at least three of four of the nails at a time, draw along the outside of the curve marked by the batten. Then push the batten against the adjacent nails farther along, and continue drawing the line, overlapping your marks as you go. After marking a complete curve, place your eye down near the panel at one end of the curve to check to make sure the curve marked doesn't weave in and out. If a nail needs to be moved more than about ½", re-check the dimensions and markings.

CUTTING:

One way we've found to cut plywood is to place it down flat on strap boards, spaced about a foot apart on a firm surface. The depth of the blade of a hand-held circular saw should be set to ½" to ⅝" below the depth of the plywood to be cut. A circular saw with a sharp combination blade can produce smooth, even curves, giving you a steady, straightening tendency to push against. Make sure there aren't any nails in the scrap lumber used as a back up, or they can ruin your blade in no time. It's much easier to follow a line with a sharp blade, and easier yet if you wear protective eye coverings so you can watch the blade closely. It's good practice to wear eye protection whenever running power tools.

ASSEMBLING:

To fasten plywood panels to the frame lumber, we used 1", #8 plated flathead wood screws (Phillips head, if possible). To attach 1" stock to other frame parts, we used 1½", #8 plated flathead wood screws.

Before driving each screw, a pilot hole is drilled. Since there are a lot of screws, it's worthwhile to get a 1", #8 combination screw hole/countersink bit for your drill (and a 1½", #8 bit, as well). Another tool that we think is essential to a boat builder is a pushy screwdriver. With it and a countersink drill bit, you can cut your building time in half—and save your wrist muscles. Yankee screw drivers are expensive, but they'll change the way you think about assembling projects and you'll find yourself tackling bigger jobs with confidence.

On all seams we marked the screwholes first with a yardstick, 3" apart, then drilled and drove screws in one at a time, aligning edges of the parts as we went. Screws should be inset from the panel edges so they sink into the centers of the stringers.

We used water mix, waterproof glue. Make sure it says on the label that it can stand immersion (it'll usually have a picture of a boat, indicating marine use on the label). Mix only a part at a time by adding just a little water and stirring until it balls up into a paste. Then you can add a little more water to thin it to a slightly runny paste, so it's wet enough to soak in, but not thin enough to run off.

Depending on the dryness of your lumber and the grain of each particular piece, some stringers will have to be "kerfed" in order to make the bends without cracking. To kerf, simply figure out which side of the stringer faces the inside of the curve (as shown later), then saw partway into this side, every 3" to a depth of ¼" to ⅝".

HULL BUILDING STEPS:

Fig. #6 shows the four basic hull building steps. To get under way we first cut one 4' × 8' plywood panel across at midpoint, to get two 4' × 4' panels. Then one of the two 4' × 4' panels was aligned with a 4' × 8' panel (with the edges aligned parallel). The side curves of the hull bottom were lofted onto these panels (using the method already mentioned), then we placed another set of ply wood panels directly under the marked panels and cut through the hull top and bottom panels simultaneously. We chose the better set of panels to form the bottom panels. Then the cockpit cut out was lofted onto the hull top panels only, and cut out, rounding the corners with a keyhole saw or saber saw. Now, the bulkheads, both sides and interior hull framing parts were cut, as shown in Figs. #3 and #4.







Marking for the bevels on the frames and bulkheads can be done with a sliding bevel gauge, but we found it easier to use a framing square with an arrow, for hull bottom frames, and a carpenter's square for the hull sides. Lay the square on the wood with the arrow pointing in the direction you want to mark, and the edge of the square on the edge of the wood. Then draw a line along the edge of the square. Now, slide the square over to the next station mark and draw another line. Then, connect the lines with a batten.

Screw the bulkheads to the hull bottom panel, then screw the hull sides to the bulkheads. Now, screw the transom to the bulkheads and hull sides. Then, screw the hull bottom panel to the bulkheads and hull sides.

Cut the deck panels to fit, and screw them to the bulkheads, hull sides and transom. Then, screw the deck joiners to the deck panels.

Cut the cockpit coaming to fit around the cockpit, and screw it to the deck. Then, screw the deck to the hull sides, bulkheads and transom.

Cut the rudder and tiller to shape, and drill the rudder for the pintles and the tiller for the rudder head. Then, screw the pintles to the rudder, and the rudder head to the tiller. Then, screw the gudgeons to the transom, and mount the rudder assembly.

Cut the daggerboard to shape, and screw the hardwood edging to the leading and trailing edges. Then, drill a hole for the pivot bolt, and mount the daggerboard in the trunk with a bolt and wing nut.

Cut the mast to length, and mount the mast step to the bottom of the mast box. Then, mount the mast in the box with a bolt and wing nut.

Cut the boom to length, and mount the gooseneck to the boom and mast. Then, mount the boom to the mast with the gooseneck.

Cut the sail to shape, and sew the hem around the edges. Then, sew the batten pockets to the sail, and insert the battens. Then, sew the sail to the mast, boom and gaff. Then, rig the sail with halyards, sheets, and downhaul.

Launch the boat, and enjoy sailing!







To assemble Bow Framing:

- Cut and assemble Dagger-board box.
- Attach stringers to the front and Mast Box to the rear of Bulkhead #1.
- Attach stringers at top and bottom of Nose Frame.
- Mock-up components in place (with 1 x 4 spacers) and trim for exact fit.
- Attach Daggerboard Box, Bulkhead #1, 1 x 4" spacers, and Nose Frame in that order.

We used 1" x 4" spacers between the bulkheads to hold the hull sides apart at the proper distance. We placed the bottom panel on the bottom edges of the hull sides, and screwed through the bottom panel into the bottom edges of the hull sides. Then, we screwed through the hull sides into the edges of the bulkheads, and into the ends of the spacers.

Next, we screwed the deck panels to the bulkheads, hull sides, and spacers. Then, we screwed the deck joiners to the deck panels.

Next, we cut the cockpit coaming to shape, and screwed it to the deck. Then, we screwed the deck to the hull sides, bulkheads, and transom.

Next, we cut the rudder and tiller to shape, and drilled the rudder for the pintles and the tiller for the rudder head. Then, we screwed the pintles to the rudder, and the rudder head to the tiller. Then, we screwed the gudgeons to the transom, and mounted the rudder assembly.

Next, we cut the daggerboard to shape, and screwed the hardwood edging to the leading and trailing edges. Then, we drilled a hole for the pivot bolt, and mounted the daggerboard in the trunk with a bolt and wing nut.

Next, we cut the mast to length, and mounted the mast step to the bottom of the mast box. Then, we mounted the mast in the box with a bolt and wing nut.

Next, we cut the boom to length, and mounted the gooseneck to the boom and mast. Then, we mounted the boom to the mast with the gooseneck.

Next, we cut the sail to shape, and sewed the hem around the edges. Then, we sewed the batten pockets to the sail, and inserted the battens. Then, we sewed the sail to the mast, boom and gaff. Then, we rigged the sail with halyards, sheets, and downhaul.

Finally, we launched the boat, and enjoyed sailing!

Bulk Rate
U.S. POSTAGE
PAID
Del Mar Co.
Permit #63



side panels. We marked the positions of the top stringers of the bulkheads and nose frames, then removed the panels, spread glue onto the joining surfaces on the bottoms of the panels and top edges of the hull stringers, then drove in all screws, spacing them 3" apart, to pull the panels down evenly onto the hull frame (with the frame block up level). We used the directions shown in Fig. #10, first driving in locating screws marked with stars, then driving in screws along the directions shown by the arrows, working rapidly while the glue was fresh. Then we drove screws down into the tops of the #1 bulkhead and nose frame.

1" × 2"s (as shown in Fig. #12) were cut to fit along the sides of the cockpit, up under the deck panel. These were attached with 1" screws spaced 3" apart. Then short scraps of 1" × 2" were mounted under the deck panel butt joint to hold the surface of the panels flush (like the panel joiners used on the hull sides).

We carefully measured where the slots in the daggerboard box top and bottom, as well as the mast hole in the hull top, would lie. Then we drilled ¼", holes within these marks and cut out the daggerboard slots flush with the slots cut in the daggerboard box top and bottom. We squeezed sealer between the deck bottom and box top, then drove screws down through the deck and into the box top, spaced 3" apart. We drilled a 1" hole down into the deck over the mast box, then sighted down into the box, centered on outline of the box opening over the walls of the box, marked a 2¼" circle within these walls, then cut out the circle with a saber saw. Again, sealer was squeezed in between the bottom of the deck and the top of the box and screws were driven down through the deck and into the stringers to the outsides of the box sides.

FINISHING:

The first step in finishing is to round off all corner edges with a Surform shaper to provide nice smooth curves with evenly radiused corners (the rounder the better)—except for the transom side and top edges (rounding the bottom edge only to prevent it from being too fragile). Next, all gaps, cracks and screw heads should be filled with catalyzed polyester auto body putty. There are a few tricks to using this that can save a lot of time and make it an easy job to smooth the hull.

Mix up small batches (about ½ cup at most) on a smooth board or palette. Squeeze out about a 25 cent piece size blob of catalyst and mix quickly with turning strokes using a 2" or 3" putty knife. (Use a separate stick to dish out the putty from the can, preventing the catalyst from entering the can). As soon as the putty is mixed to a uniform gray-red (or grass-blue, depending on the brand), smooth it into the largest gaps to be filled first. Too much catalyst (making a dark colored putty) will make the putty harden too fast; too little (making a light gray mix) will prevent it from hardening, so stick with a "hotter" mix to begin with and work fast. On a hot day you'll need less catalyst, and never work in full sunlight or it will always harden too fast.

Work the putty rapidly into the depressions to be filled, smoothing out air bubbles and leaving a lump where there was a hole (smoothing it flat will result in a dent when the putty "goes off" and shrinks).

As soon as the putty begins to lump like cottage cheese on the palette, stop applying it and clean up the palette and putty knife. In a few minutes it will get like Swiss cheese (a good time to peel any spills off the floor). Then it will gradually harden to the point where you can scratch it with your fingernail and leave a white mark. At this point you can use the Surform (gently at first) to shave away great amounts of putty easily and quickly (like grating cheese). This will last about ten minutes, so work fast and you can smooth the whole batch in a few minutes. After the whole boat has been filled and smoothed, you can mix up slightly "cooler" batches and give the filled spots a careful second treatment to fill any exposed air bubble holes, smoothing them off flush with the surface.

Next, sand with about 80 grit paper, then sand with 150 grit paper, and begin painting, sanding with finer paper between coats.

A good initial paint job of oil base, gloss enamel will prevent maintenance problems later on. The first coat is only a seal to permit finish sanding. The second coat will show where any final finish puttying is needed. Make sure coats are well dried before applying the next. Just before painting, give the hull a light sanding and rub down with thinner to clean it well and prevent "fish eyes" from forming and to remove dust. Don't paint in direct sunlight (to prevent bubbles), nor outside late in the afternoon (any dew will turn the paint flat). Thick coats tend to sag on the surface, then run into sags underneath. Even applications of thinned paint prevents drips. You can thin with paint thinner (but then you lose covering ability) or you can thin the paint by warming it in the house to retain coverage and get a good flow. If the brush tags or loses bristles as you paint, the paint probably needs thinning. Use parallel, long strokes as you finish a surface.

A good paint job will take four to six coats, but can effectively prevent checking and cracking for years, even when the boat is stored outside.

Attach hefty lifting handles to the hull ends (two at the rear) about 12" in from the ends so long screws will grab into the framing stringers.







CONTROLS:

The daggerboard was cut from a 44" piece of clear fir 1" × 12". After cutting to the shape shown in Fig. #9, left, we drilled a ½" hole in the front and rear edges (as shown) and through the side at the top. Then we drove in short lengths of ½" dowel (with glue) and trimmed them off about 1" out from the sides to provide stops and a lifting handle for the board. To prevent the board from floating up, a short length of shock cord can be screwed to the deck over the slot in the deck, which can be slipped over the top of the board when under way.

We marked where the board stuck out below the hull bottom, then drew a line around the center of the edges of the board below the hull line and faired off the edges of the board to a slightly rounded point (fairing the board and the rudder not only increases top speed, but also adds to the control power of these surfaces).

To build a rudder box to hold the pivoting, raisable rudder, we lofted the rudder box side (shown in Fig. # 9, top, left), onto a plywood scrap, cut it out and used it as a pattern to mark and cut an opposite box side from another plywood scrap.

Next, we cut the spacers to the sizes shown in Fig. # 9, then attached spacers "A" and "C" to one box side with screws and glue with the ¼" side of the spacers against the box side so the box sides will end up ¾" apart. We marked and drilled the ¼" pivot bolt hole as shown, then attached the second side to the spacers, drilling the pivot hole on through this side as well. The cap strip "B" was then screwed to the front of the box, as shown, with 1½" screws and the pivot strips from the barrel bolts were then screwed to this cap strip in the position shown at center, right in Fig. # 9.

The rudder was rough-cut to the shape shown at upper right, Fig. # 9, then the tiller was cut to the shape shown. We drilled ¼" holes about 2" deep into the top edge of the rudder and the back end of the tiller as shown. Then we twisted open a 3" × ¼" screw eye, slipped another 3" screw eye onto the opened one, and retwisted the first screw eye closed, linking the pair.

Next, we twisted one of the screw eyes down into the top edge of the rudder, then twisted the tiller onto the corner screw eye. We drilled the ¼" pivot hole in the rudder as shown, then drilled the ¼" hole for the lock bolt on the front arm of the rudder box, shown at lower right, Fig. # 9. This bolt was inserted in place, then we slipped the rudder/tiller assembly into the rudder box and inserted the pivot bolt. We marked where the tiller rested on the lock bolt with the rudder in the "down" position. Then we pulled the tiller forward, raising the rudder, and marked where the tiller rested on the bolt in the "up" position. Notches were then cut into the bottom edge of the tiller so that the rudder position could be locked by pushing the tiller notches down over the lock bolt. Finally, we trimmed off the top, rear corner of the tiller and rudder to follow the curve of the rudder box, and faired the lower edges of the rudder off to a rounded shape. We twisted the screw eyes a little so they could clear the sides of the rudder box.

RIGGING:

Sometimes the hardest step of rigging your boat can be finding the right tubes, and we've come across a couple of tricks that may save you headaches and time. First of all, never use the phone to hunt down a tube supplier. When you call up to find a certain material, you rarely get a chance to talk to the person best qualified to answer your questions. What you usually get is a fast answer rather than an accurate one—one that will get you off the phone in a hurry.

Many times we've found that a distributor may actually have just what you're looking for, but it may take a bit of game-playing to get access to it. First, it's a good rule to show that you're sufficiently concerned about tracking down the material to show up in person. Next, don't scare the man off by loading him down with a bunch of confusing specifications until you get a chance to look over what he has in stock.

Just have a general idea of what you're looking for, and ask to help look around for it. If you simply call and rattle off a bunch of numbers, they'll usually pass you on to the next supplier in the Yellow Pages. Large distributors of tubing and raw materials won't want to bother with such a small retail order and will quote an astronomical price—if they deign to give one at all.

Salvage scrap and surplus yards sell aluminum tubing and material by the pound, and you shouldn't spend much over thirty dollars for a rig. Another good source is irrigation suppliers, who can usually sell three twenty foot lengths for under thirty dollars. However, irrigation pipe is a little thinner and softer than most tubing stock, and should be reinforced with clear fir 1" × 3" boards trimmed to fit snugly inside the pipe. Shorter pieces can be spliced together in the same way, with 2" × 2" stock trimmed to fit.

What's the best tubing to look for? Anything from 2" to 2½" diameter aluminum tube (2¼" is best) with a wall thickness of around ½," or .065". If you have a choice of tempers, 6061-T6 seems to have the right sort of hardness, springiness and resistance to corrosion. As we said, however, wood reinforcers can be used for softer pipes enough for use. Some builders report good luck with auto exhaust pipe welded up from 10' lengths.

To start rigging the boat, cut the tubes to the lengths shown and rip the 1" x 3" clear fir or spruce reinforcing strips to fit snugly in the tubes (if needed). If the tube seems to lack springiness, or is a little on the thin side, we generally run reinforcing up the mast about three quarters of the way to the top, and down from the top of the upper boom (or gaff) down to about the center of the tube. After inserting the strips, drill all hardware mounting holes so that the strips will be held with their wide sides lying across the direction of the boat (athwartship).

After the rig is assembled, the sail will be cut, and the rig is attached to the gaff and boom pockets. The mast foot can be slipped down into the mast box, and the gaff can be raised by pulling down on the line running from the gaff, through the pulley block at the top of the mast and back down to be tied to the cleat near the base of the mast.

To connect the front ends of the gaff and boom, drill a ⅜," hole through both tubes about 1" back from the end (and through the reinforcers, the long way, if used). Then slip each end of a ⅜," x 3" U-bolt (check the materials list for exact specifications of the galvanized iron hardware used throughout the construction of the rig), through the tube holes, run on a nut, slip on the two-hole washer strip, and run on double locknuts and tighten securely.

The gooseneck is made up of two galvanized iron eyebolts. With pliers or a vise, twist the loop of one eyebolt so the loop of the second eyebolt can be slipped onto it. Then hammer or twist the opened eyebolt back closed again. Drill a ⅜," hole, as shown, through the mast (and through any reinforcer the long way) and through the boom, as shown, parallel to the hole drilled through the same tube at the front. Insert the ends of the joined eyebolts through the holes in the tubes and secure with double locknuts, and trim off the leftover bolts.

The halyard pulley block is held to the top of the mast with a ⅜," eyebolt mounted through a hole drilled about 1" down from the top and at right angles to the hole drilled through the mast for the gooseneck below. Open the bolt eye, slip on a block and reclose. The halyard line is tied neatly to the gaff in the position shown, then the knot is wrapped tightly with 2" grey duct tape to lock it in position.

After raising the gaff with the halyard, the free end of the line is tied to a galvanized cleat mounted vertically, as shown, near the base of the mast. Mount the cleat to the mast by drilling starter holes and then attaching the cleat with large sheetmetal screws driven into the mast.

To tie a line to a cleat, pull the line tight, wrap it once around the base of the cleat, then lead the line up over the center of the cleat, looping it over one ear of the cleat—then back over the center and loop it over the other ear. After looping the ears of the cleat a few times, make a final loop, twist it so that the free end of the line is now under the line from the previous, slip it over the ear and pull the free end tight.

When you pull the gaff up, you'll have a lot of loose line lying around the deck and to prevent this from falling overboard, loop the free line in a coil and tie to the top ear of the cleat by reaching through the coil to grab the line leading from the cleat to the coil, pulling it back through the loops in a twisted loop, and slipping this loop over the top ear of the cleat.

Twist open two 3"&5/16" eyebolts and slip a single pulley onto one and a double pulley on the other and close both. Drill a vertical ⅜" hole through the boom about 2" forward of the aft end and bolt the double pulley to the bottom of the boom. Drill and attach the single pulley forward on the boom in the position shown.

To hold the mainsheet (the line controlling the sail position) to the hull, cut a 4" length off the mainsheet line. Tie a single pulley to the very center, then tie a snap hook to both ends. To rig for sailing, snap each of the hooks over one of the left handles at the rear of the boat, then insert one end of the mainsheet through one side of the double pulley on the boom and tie a simple knot so it can't be pulled back through. Run the free end of the mainsheet through the pulley attached to the hull, then back up through the other side of the double pulley, forward through the front boom pulley and from there back down to the cockpit. It's a good idea to tie the mast to the forward lift handle, as well (you can use the end of the halyard) to attach it to the boat.





COAMING AND COCKPIT DETAIL:

You can use a grit texturing, described in the FINISHING steps, a texturing additive for the paint or rubber matting contact glued to the cockpit floor to give some traction for safe sailing in higher winds. We also cut ribbed rubber matting to form slip-resistant seats on both sides of the cockpit (as shown in Fig. #12).

In rough water you'll get wet in a boat like this, which is why hot sailers are wearing wet suits for real action. But even in smooth water a thin film of water can creep up over the deck on a fast tack, and spill into the cockpit, unless you have a coaming.

We used regular garden hose to form a knock-resistant flexible coaming for this purpose. We cut about ten 2" lengths of wood dowel to fit inside a hose (we used ¾" dowel in a ¼" hose), pushed the dowels into the hose about 3" apart using a stick, then drilled ⅜" holes down through the hose and the dowels and drove 1" screws down through the holes in the dowels and hose to attach it to the deck (following an 17" radius arc with its from 16" forward of the cockpit). We used a white hose, then filled the screw holes and the corners between the deck and both the front and rear side of the hose (as shown in Fig. #12) with DAP flexible tub and tile caulk.

MAKING THE SAIL:

Years ago we brought out a way to make inexpensive sails in a couple of hours out of 6 mil polyethylene. The plastic sails proved themselves (in land sailer speeds above 30 knots) to be rugged and good for high speed use, but a little reduced on power in lighter winds, and somewhat vulnerable to abrasion in transporting them to the water. Recently we've tried out a new sail material using sun-resistant, rip-stop woven and laminated plastic tarpaulins and sewn-in seam ropes. They cost about $30, but they're extremely rugged, resistant to ultraviolet rays, have an already sewn-in leech line and they take on a nicer shape for better low-wind performance. Plus you can get two sails out of one tarp which brings your cost down to a little over $15 per sail!

They come already colored in either orange or blue and stand up to frequent transporting extremely well. You can use the same building steps for either the rip-stop plastic or polyethylene sails with one change: When laying the rig down onto the plastic, align the aft ends of the boom and gaff with a sewn hem so that the seams in the tarp extend forward from the leech (as shown in Fig. #11) at right angles to the leech or rear hem of the sail.

If you have any difficulty in locating a hardware or surplus store that stocks plastic tarpaulins, you can use the order sheet included in the plans to order a tarp directly from us. Another option is fabric, two color sail kits available from Sailrite Kits in Columbia City, Indiana.

To make the sail shape, use a 12" wide box as a guide to slide along the outsides of the sail, while marking the plastic 12" outside the tube with a felt tip pen. Cut along the lines marked, then trim the plastic off at the boom ends at right angles to the tubes, as shown.

With small scissors cut holes along the top and bottom (but not the rear) edges of the sail. These holes should be about ¼" in diameter, with about ½" margin in from the top of the plastic. Space the holes about 4" apart.

Next, fold the edges with holes back over onto the sail, making a 12" wide pocket along the boom and gaff edges. Smooth the plastic flat along the fold, pulling the pocket material right from both ends; then use the pen to mark the exact positions of all the holes through onto the lower layer of plastic while the edge is held in position.

Cut out these holes and fold the plastic over into a pocket again and smooth out flat. Now run an unbroken strip of 2" wide grey duct tape (use the fabric-backed kind, not the all-plastic type) along the row of holes, overlapping the seam of the pocket edge. When reaching the end of the pocket at the edge of the sail, cut a 1" diameter semicircle in the sail edge and then run the tape over this, as shown. Work on a carpet, if possible, to prevent picking up dirt on the adhesive side of the tape.

Carefully turn the sail over and apply a second strip of tape to the other side of the sail, following the path of the first strip of tape, so that the adhesive of both strips of tape can grab onto each other through the holes in the sail. This is the real strength of the seam, so make certain the holes are aligned before taping. Now rub down both sides of the seam thoroughly with your fingernail, burnishing the two layers of tape adhesive together to make a good bond. Place a block of wood behind the sail and tap the taped seam with a hammer all along the edge to get an extra-strong seam. Then repeat this to tape the other seam of the sail.

To attach the sail to the rig, remove the gaff and boom from the mast and insert each into its pocket in the sail. Pull the rear ends of the boom and gaff apart so that the sail is pulled tight, then wrap tape around the tips of the sail at the ends of the tubes to attach. Cut rounded holes so that the halyard, pulley blocks and gooseneck can stick out through the pockets, then reassemble the rig.

The plastic sail itself has proved to be extremely durable in heavy wind conditions, and has given years of service. Like a dacron sail, however, it should be stored out of direct sunlight when not in use.

Before heading out for a sail, make sure you have a paddle aboard in case the wind quits early, plus a sponge to dry things off, and a Coast Guard approved life-jacket for each crew member. Keep one hand free to hold onto the boat, don't sit on the mainsheet, and keep an eye out for what's coming up.

© 1980 STEVENSON PROJECTS AND PUBLICATIONS

Because the construction of a SPORT SAILER is dependent on factors of materials used and craftsmanship that are beyond the control of the designer and the magazine publisher, neither the designer nor other contributors can accept responsibility for the performance of the boat as actually constructed.



Photos show clear polyethylene sail. When using colored Tarpaulin material, run hemmed edge along Leech (as shown in Fig. #11) with seams at right angle to leach.

SAIL OPTIONS

Sail Kits:
For information regarding kits for building the Sport Sailer, write to Sailrite Kits, R.R. #1, Columbia City, Ind., 46725. Ph. 219-244-6715

Tarps:
The Tarpaulin material described in the plans is usually found at tarp and canvas shops. However, if you have difficulty in locating the Tarps we can supply you with one large enough for two complete sails for $30, plus $5 handling and shipping (California residents please add $1.80 for sales tax).

If you're interested in more low-cost recreation projects you can build, check the box in the coupon at right and include your address to receive our free brochure including: our 14' Catamaran; 22' Pontoon Boat; Redwood Hot-Tub; miniature Indy Racer; 16' Sailing Scow; and other sailing required); super-simple beginner's Sailboat; Hydrofoil; 12' Pram for motoring, rowing, or sailing; Touring Kayak; lightweight Land Sailer; 14' Fishing Boat; Power Catamaran; Modular Greenhouse; and Traditional Skipjack Sailboat.

Please send me ____ tarpaulin(s) at $30.00 each — Total: $ ____
Available in orange or blue. First color choice: ____
Second Color choice: ____
Shipping and Handling Charges ($5.00 each) — $ ____
California Residents please add $1.80 each for Sales Tax — $ ____
TOTAL: $ ____

Please make check or money order payable to Stevenson Projects OR you may charge to your MASTERCHARGE account (SORRY, we cannot accept VISA)

Account Number: ____ InterBank Number: ____

Expiration Date: ____ Signature: ____

Please check if you'd like a free Brochure ____

SHIP TO:
NAME: ____
ADDRESS: ____
CITY: ____ STATE: ____ ZIP CODE: ____
(Please include your phone number in case we have a question:) A/C ____ Phone ____

NOTE: Please advise if United Parcel does not service your area and we will ship via Parcel Post. Please allow 2 to 3 weeks for delivery.

MATERIALS

LUMBER:
-ACX Exterior Grade Plywood (or Marine Grade):
Four- 4' x 8' x 1/4" Panels
-Clear Fir or Spruce:
Two- 14" 1" x 6" (one for side stringers; one for bulkheads and framing parts)
One- 7' 1" x 12" (for Rudder, Tiller, & Rudder Box spacers)
One- 4' 2" x 4"
One- 12' 1" x 4"
One- 6' 1" x 2"
One- 6' 1" x 2"

HARDWARE: (all galvanised)
2- sets Barrel-bolt Locks
2- 1/4"x2" Bolts
2- 1/4"x3" Screw-eyes
1- 5/16"x3"x 1-3/4" U-Bolt
1- Clothesline Cleat
1- Double Pulley (for 1/4" line)
3- Single Pulleys
5- 5/16"x3-1/2" Eyebolts
3- Large Grab-Handles
2- Plated or brass Snaphooks
4- 1/8" x 1-1/4" bolts, nuts
800- 1" plated, flathead, #8 woodscrews
100- 1-1/2" plated, flathead, #8 woodscrews
MISC.
1- quart polyester auto body filler putty
2- quarts waterproof glue
1- gallon oil-base gloss enamel
1- tube DAP or Silicon seam sealer
15- cu. ft. Expanded Polystyrene packing foam particles
50'-1/4" or 3/8" braided nylon or dacron line
5 lbs "Agrashell" medium grit or "Rol-a-Tex" paint texturing

RIGGING
1- 16' Tube, 2- 12' Tubes, (2" to 2-3/8" dia., 1/16" or .065 wall thickness: (aluminum tubing or irrigation pipe)
1- 60' roll of 2" gray duct tape (fabric backed)
Tubing Reinforcing (if needed):
1- 16' clear fir 1x3"
1- 10' clear fir 1x3"

SAIL:
1- 16' x 20' (15'-6"x 19-8" finish size when hemmed) Tarpaulin material, ("Flextuf" or "Super Duff" woven polyethylene), 6-mil clear clear polyethylene can be used

COAMING
3' x 1-1/2' Ribbed Rubber stair Tread
36" x 5/8" Wood Dowel
4-1/2" -3/4" Garden Hose

One builder wrote in to tell us that instead of cutting holes for the tape with scissors, he filled the end of a piece of ⅛" o.d. pipe (O.D.) about 2" long, so the end edge was sharp all around. Then he folded the pockets over, placed a board behind the seam and tapped the pipe with a hammer, punching a hole through both layers of plastic and a little of poly in one operation. This saves a lot of repositioning and re-marking and will more than pay your time to make a simple punch. Or you can buy a ½" diameter grommet hole punch. Using a punch this way, the builder added, he and his wife were able to make their first sail in less than two hours!