



SAILMAKER'S GUIDE

MODEL 8.6m

MODEL YEAR 1984

- | | |
|----------------------------|------------------------------|
| 1. MAINSAIL AREA (sq. ft.) | <u>186</u> |
| 2. CLASS JIB (sq. ft.) | <u>204</u> |
| 3. REEFING POINTS | <u>1 Set</u> |
| 4. MAST TUNNEL SIZE | <u>1/2"</u> |
| 5. MAINSAIL FEEDER TYPE | <u>Slide</u> |
| 6. TACK FITTING SET BACK | <u>2"</u> |
| 7. TACK FITTING SET DOWN | <u>2"</u> |
| 8. BOOM TUNNEL SIZE | <u>5/16"</u> |
| 9. TYPE of LUFF SLIDE | <u>1/2" Round</u> |
| 10. "I" DIMENSION | <u>37.0'</u> |
| 11. "J" DIMENSION | <u>11.0'</u> |
| 12. "P" DIMENSION | <u>31.0'</u> |
| 13. "E" DIMENSION | <u>12.8' 12.0</u> |